



FANTOM

FANTOM SPA DRAINING VALVE LOCATION

To help you clean your spa, we've added a **draining valve**.

Here's where
it's located
on the
Fantom spa



When you're standing outside the spa, facing the keyboard, **the drain is on the left-hand side, at ground level.**

DRAINAGE FREQUENCY

You should drain and refill your spa every **one to three months** depending on usage. You should also replace the filter cartridge and wipe down the spa.

For any questions, please contact our service department:

(00 +1)-450-565-5544 ext. 226 or 227